


INSTALLATION GUIDE

VIGILEC®
zero^{plus}
sensor

1







2





3




4



5



6



7

